

EA501 Passive Infrared Motion Alarm

Undo the 4 screws and remove the cover securing the battery compartment on the main unit. Insert 3 "AA" batteries (not included), following the correct polarity indicated inside the unit. Replace the battery cover using the 4 screws.

Remove the plastic tabs from the 2 remotes to activate the batteries.

Fitting the main unit

Using the bracket provided, fit the alarm unit at a height of 1.85 – 2.50m for maximum coverage. Avoid pointing at windows in direct sunlight.

Test the coverage, whilst set, by walking in front of the of the main unit and adjusting the angle of the unit on the bracket.

To set

Point the remote at the red lens of the main unit and press the remote button once. You will hear a bleep and a green light will show for 10 – 15 seconds allowing time to vacate the area. When the green light goes out the alarm is set. Once set, if any movement is detected in front of the main unit, a red light will flash for 5 seconds and then the alarm will activate.

To deactivate

The alarm can be deactivated at any time with the remote. Point the remote at the main unit and press the button once. The alarm will bleep once to indicate it has been deactivated. If the alarm is not deactivated by the remote it will reset after 30-40 seconds.

When using this product follow these battery precautions.

- Use only the appropriate size batteries.
- Be sure to follow the correct polarity when installing the batteries as indicated in the battery compartment. Incorrect polarity may cause damage to the alarm.
- Do not mix different types of battery such as Alkaline and Carbon-zinc or old batteries with new.
- If the alarm is not used for long periods of time, remove the batteries to prevent damage or injury from possible battery leakage.
- Do not recharge batteries not intended to be recharged as they can overheat and rupture. (Always follow the manufacturer's directions).